





INVESTIGATION METHODS TO DISTINGUISH BETWEEN VAPOR INTRUSION AND INDOOR SOURCES OF VOCS

Thomas McHugh and Lila Beckley, GSI Environmental, Inc.
Tomasz Kuder and Paul Philp, University of Oklahoma
Kyle Gorder, Hill AFB
Ignacio Rivera and Bart Chadwick, Navy SPAWAR
Stephanie Fiorenza, BP America

Report Documentation Page

Form Approved OMB No. 0704-0188

Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.

1. REPORT DATE NOV 2010	2. REPORT TYPE	3. DATES COVERED 00-00-2010 to 00-00-2010	
4. TITLE AND SUBTITLE Investigation Methods to Distinguish Between Vapor Intrusion and Indoor Sources of VOCS		5a. CONTRACT NUMBER	
		5b. GRANT NUMBER	
		5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)		5d. PROJECT NUMBER	
	5e. TASK NUMBER		
	5f. WORK UNIT NUMBER		
7. PERFORMING ORGANIZATION NAME(S) AND AI GSI Environmental Inc,2211 Norfolk,	8. PERFORMING ORGANIZATION REPORT NUMBER		
9. SPONSORING/MONITORING AGENCY NAME(S) A	10. SPONSOR/MONITOR'S ACRONYM(S)		
		11. SPONSOR/MONITOR'S REPORT NUMBER(S)	

12. DISTRIBUTION/AVAILABILITY STATEMENT

Approved for public release; distribution unlimited

13. SUPPLEMENTARY NOTES

Presented at the 15th Annual Partners in Environmental Technology Technical Symposium & Workshop, 30 Nov? 2 Dec 2010, Washington, DC. Sponsored by SERDP and ESTCP. U.S. Government or Federal Rights License

14. ABSTRACT

Indoor sources of volatile organic chemicals (VOCs) are ubiquitous, resulting in detectable concentrations in indoor air, often at concentrations above regulatory screening levels. At VOC contaminated sites with potential vapor intrusion concerns, the presence of indoor VOC sources significantly complicates the exposure pathway investigation. Because of these indoor sources, the detection of a site-related VOC in a potentially affected building at a concentration above the regulatory screening level does not necessarily indicate a vapor intrusion impact. Instead, additional analysis is required to determine the sources of the detected VOCs. We have developed several approaches to distinguish between vapor intrusion and indoor sources of VOCs including: (i) use of a field-portable gas chromatograph/mass spectrometer (GS/MS) to evaluate the distribution of VOCs within a building and to identify specific indoor sources of VOCs, (ii) collection of indoor air and sub-slab soil gas samples under controlled negative building pressure conditions designed to maximize vapor intrusion and controlled positive building pressure conditions designed to inhibit vapor intrusion, and (iii) use of compoundspecific stable isotope analysis to determine the original source of VOCs detected in indoor air samples. Each of these methods has been has been applied to one or more buildings potentially impacted by vapor intrusion and has proved useful to distinguish between vapor intrusion and indoor sources of VOCs.

15. SUBJECT TERMS								
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF	18. NUMBER OF PAGES	19a. NAME OF RESPONSIBLE PERSON			
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified	Same as Report (SAR)	26	RESI GIGIDEL I ENGON			

INVESTIGATION METHODS TO DISTINGUISH BETWEEN VAPOR INTRUSION AND INDOOR SOURCES OF VOCS

THOMAS MCHUGH GSI Environmental Inc. 2211 Norfolk, Suite 1000 Houston, TX 77098 (713) 522-6300 temchugh@gsi-net.com

Indoor sources of volatile organic chemicals (VOCs) are ubiquitous, resulting in detectable **L**concentrations in indoor air, often at concentrations above regulatory screening levels. At VOC contaminated sites with potential vapor intrusion concerns, the presence of indoor VOC sources significantly complicates the exposure pathway investigation. Because of these indoor sources, the detection of a site-related VOC in a potentially affected building at a concentration above the regulatory screening level does not necessarily indicate a vapor intrusion impact. Instead, additional analysis is required to determine the sources of the detected VOCs. We have developed several approaches to distinguish between vapor intrusion and indoor sources of VOCs including: (i) use of a field-portable gas chromatograph/mass spectrometer (GS/MS) to evaluate the distribution of VOCs within a building and to identify specific indoor sources of VOCs, (ii) collection of indoor air and sub-slab soil gas samples under controlled negative building pressure conditions designed to maximize vapor intrusion and controlled positive building pressure conditions designed to inhibit vapor intrusion, and (iii) use of compoundspecific stable isotope analysis to determine the original source of VOCs detected in indoor air samples. Each of these methods has been has been applied to one or more buildings potentially impacted by vapor intrusion and has proved useful to distinguish between vapor intrusion and indoor sources of VOCs.



VAPOR INTRUSION VS. INDOOR SOURCES


- Background: Indoor Sources
- On-Site GC/MS
- Building Pressure Control
- Compound-Specific Stable Isotope Analysis





PROBLEM: INDOOR SOURCES

- At a vapor intrusion site, testing of indoor air is the most direct way to identify VI impacts.
- Indoor sources of VOCs are ubiquitous: cleaners, glues, plastic, etc.
- Detection of VOCs in indoor air does not necessarily indicate vapor intrusion.



Key Point: Critical need for reliable methods to distinguish between vapor intrusion and indoor sources of VOCs.

2004 Background vs. USEPA Risk-Based Limits



Senzene

Sourcentration (ng/m³)

Indoor 1


Ambient 1

90th %

Median

10th %

INDOOR AIR LIMIT²



KEY POINT: Background indoor and outdoor air concentrations commonly exceed risk-based limits for indoor air.

¹⁾ Background concentrations from Sexton et al. 2004 ES&T 38(2); 423-430.

²⁾ USEPA Master Screening Values Table, September 2008

But We Don't Use "TOXIC" Chemicals Anymore



Email bulletin from vendor, October 2010:

Technical Update

Topics, trends, and news in the environmental industry...

TCE Contamination Affects Community's Water Wells

"The TCE, which was banned from public use in the 1970s, was detected at levels greater than the U.S. EPA's maximum contaminant level for public drinking water."

KEY POINT: Many people believe that TCE and other chlorinated solvents are no longer used in industrial operations or consumer products.







THE THE PERSON OF THE PERSON O





Gun Cleaner: \$19.95

>90% TCE

Pepper Spray: \$3.99

>90% TCE

Brake Cleaner: \$12.95 50/50 TCE/PCE Solvent Degreaser: \$15.95 >90% TCE

KEY POINT: TCE, PCE, etc., are legal and are still used in a wide range of consumer products currently available for purchase.



INDOOR SOURCES: Remove before sampling







INDOOR SOURCES: Find'em if you can





Key Point: Source remove often not practical or effective.

Need investigation program that deals with indoor sources.



POTENTIAL METHODS TO DISTINGUISH BETWEEN VAPOR INTRUSION AND INDOOR SOURCES OF VOCS

Real-time On-site Analysis

- Used successfully by USEPA and Hill AFB
- Requires expensive equipment: Hapsite GC/MS or USEPA TAGA unit.

Building Pressure Control

- Current ESTCP Project ER-0707
- May not be suitable in very large or very leaky buildings.

CSIA / Fingerprinting

- Completed "Proof of Concept" study
- Potentially simplest method to apply on routine basis.

KEY Indoor "fear factor" will disappear when we can POINT: accurately identify the source of the VOCs.



POTENTIAL METHODS TO DISTINGUISH BETWEEN VAPOR INTRUSION AND INDOOR SOURCES OF VOCS

Real-time On-site Analysis

- Used successfully by USEPA and Hill AFB
- Requires expensive equipment: Hapsite GC/MS or USEPA TAGA unit.

Covered by Kyle in previous talk







POTENTIAL METHODS TO DISTINGUISH BETWEEN VAPOR INTRUSION AND INDOOR SOURCES OF VOCS

Real-time On-site Analysis

- Used successfully by USEPA and Hill AFB
- Requires expensive equipment: Hapsite GC/MS or USEPA TAGA unit.

Building Pressure Control

- Current ESTCP Project ER-0707
- May not be suitable in very large or very leaky buildings.

CSIA / Fingerprinting

- Completed "Proof of Concept" study
- Potentially simplest method to apply on routine basis.


KEY Indoor "fear factor" will disappear when we can POINT: accurately identify the source of the VOCs.

PRESSURE CONTROL: OVERVIEW



Concept:

- 1) Use controlled NEGATIVE building pressure to MAXIMIZE vapor intrusion.
- 2) Use controlled POSITIVE building pressure to TURN OFF vapor intrusion.





CONTROL OF BUILDING PRESSURE















ASU HOUSE: BUILDING PRESSURE



EFFECT OF BUILDING PRESSURE ON INDOOR RADON CONCENTRATION

ASU RESEARCH HOUSE







Key Point: Control of building pressure resulted in control of radon vapor intrusion.

ASU HOUSE: VOC CONCENTRATIONS





MOFFETT BLD 107: BUILDING PRESSURE





POTENTIAL METHODS TO DISTINGUISH BETWEEN VAPOR INTRUSION AND INDOOR SOURCES OF VOCS

Real-time On-site Analysis

- Used successfully by USEPA and Hill AFB
- Requires expensive equipment: Hapsite GC/MS or USEPA TAGA unit.

Building Pressure Control

- Current ESTCP Project ER-0707
- May not be suitable in very large or very leaky buildings.


CSIA / Fingerprinting

- Completed "Proof of Concept" study
- Additional funding for development and validation.

KEY POINT: Multiple methods available to distinguish between vapor intrusion and indoor sources.


ESTCP

TECHNOLOGY DESCRIPTION






ISOTOPE RATIOS FOR INDOOR SOURCES





RESULTS FOR INDOOR AIR




FINDING:

GW with TCE discharged into sewer.

TCE is moving from sewer into house.



RESULTS FOR INDOOR AIR




FINDING:

PCE in indoor air is from indoor source.

(Source later identified as E6000 glue)



RESULTS FOR INDOOR AIR



FINDING:

TCE in indoor air matches TCE in GW.

TCE is too heavy to be an indoor source.

> Vapor Intrusion

SUMMARY: CSIA FOR VAPOR INTUSION



Sample Collection

- Sorbent tubes (active sampling) can be used to collect VOC samples for CSIA
- Conducting further validation to evaluate robustness of sampling method

Source Identification

Preliminary results support the hypothesis that <u>INDOOR</u> and <u>SUBSURFACE</u> sources of VOCs will often have <u>different isotope</u> <u>signatures</u>

CSIA for Vapor Intrusion

 For some buildings, CSIA will provide clear results based on <u>ONE</u> indoor air sample and <u>ONE</u> subsurface sample



ACKNOWLEDGEMENTS

Work funded by:

ESTCP Projects ER-200707 and ER-201025

AFCEE BAA Contract 09-C-8016

Hill AFB/BP America – CSIA "Proof of Concept"

Special Thanks to:

Roger Lee, Sims & Associates
Sam Brock & Erica Becvar, AFCEE
Erik Dettenmaier, Hill AFB
Lisa Molofsky, Danny Bailey, Roberto Landazuri, GSI Env. Inc.
Paul Johnson's Research Team, Arizona State University
Beacon Environmental